

PERGO® Gold™

Premium Underlayment

INSTRUCTIONS:

- 1) Be sure the floor is clean and dry before installing underlayment. Pretest substrate for moisture emissions prior to installation of underlayment. Ensure that the underlayment seams will run perpendicular to the flooring seams.
- 2) Starting in a corner, install the first row of underlayment with the non "lip and tape" side up against the wall and the overlapping "lip and tape" side towards the open side of the room. The gold moisture barrier must be facing upward. Install the underlayment to the far wall and cut around any obstacles using a utility knife.
- 3) Align the second row of underlayment to the first row.
- 4) Flip the first row's overlapping lip onto the second row and secure it using the adhesive tape strip located on the overlapping lip. To activate the adhesive, remove the liner and apply hand pressure to seal the seams.
- 5) Repeat this process until the entire floor is covered and sealed. Ensure that all foam seams without the overlapping lip tape are sealed with underlayment seam tape (sold separately). It is not necessary to tape the outer perimeter of the room's underlayment. After underlayment installation is complete, install your flooring according to the manufacturer's instructions.

SPECIFICATIONS:

Dimensions:

3 mm thick x 4 ft wide x 25 ft long

Moisture Protection:

0.01 pounds/24 h/1,000 sq ft

Impact Sound Insulation:

IIC 71/STC 66/Delta 21

Thermal Insulation:

R-Value 0.53

Smoothing:

2.5 mm

Compression Strength:

> 15 PSI

Safety:

Odorless, non-toxic,
100% recyclable



PERGO® Gold™

Contrapiso de primera calidad

INSTRUCCIONES:

- 1) Asegúrese de que el piso esté limpio y seco antes de instalar el contrapiso. Revise la humedad en un subsuelo de concreto antes de instalar el contrapiso. Asegúrese de que las uniones del contrapiso vayan de forma perpendicular hacia las uniones del piso.
- 2) Desde una esquina, instale la primera fila de contrapiso con el lado sin "reborde y cinta" hacia la pared y el lado de "reborde y cinta" que se superpone hacia el lado abierto de la habitación. La barrera dorada contra la humedad debe mirar hacia arriba. Instale el contrapiso hacia la pared más lejana y corte alrededor de los obstáculos con un cuchillo para uso general.
- 3) Alinee la segunda fila de contrapiso con la primera fila.
- 4) Coloque el reborde de la primera fila que se superpone sobre la segunda fila y asegúrela con la tira de cinta adhesiva que se encuentra en el reborde que se superpone. Para activar el adhesivo, retire el forro y haga presión con las manos para sellar las uniones.
- 5) Repite este proceso hasta que todo el piso esté cubierto y sellado. Asegúrese de que todas las uniones de espuma sin la cinta del reborde que se superpone estén selladas con cinta para uniones de contrapiso (se vende por separado). No es necesario colocar cinta en el perímetro exterior del contrapiso de la habitación. Despues de completar la instalación del contrapiso, instale el piso según las instrucciones del fabricante.

ESPECIFICACIONES:

Dimensiones:

3 mm de espesor x 7,62 m de largo
x 1,21 m de ancho

Protección contra la humedad:
0,01 libras/24 h/1000 pies²**Aislamiento de sonido por impacto:**
IIC 71/STC 66/Delta 21**Aislamiento térmico:**
Valor R 0.53**Alisado:**
2,5 mm**Resistencia de compresión:**
> 15 PSI**Seguridad:**
Es inodoro, no es tóxico,
100% recicitable